

# GOAL JUDGE REMOTE



## OPERATION

### REMOTE CABLE CONNECTOR

- Match the slot on the remote cable connector and remote cable and fix the turns to connect cable tightly.

### COMMUNICATION AND POWER LEVEL INDICATOR

#### RED light:

- Communication issue between ISC EDGE CONTROLLER and GOAL JUDGE REMOTE. Good power level.

#### BLUE light:

- Communication between ISC EDGE CONTROLLER and GOAL JUDGE REMOTE not established successfully. Good power level.

#### GREEN light:

- Communication between ISC EDGE CONTROLLER and GOAL JUDGE REMOTE established successfully. Good power level.

### Goal Light Left

- Press the "L" button to activate the goal light on the Left end of the arena (from the perspective of the game clock operator).

### Goal Light Right

- Press the "R" button to activate the goal light on the Right end of the arena (from the perspective of the game clock operator).

